Tamson Instruments Specification sheet

High Temperature Foaming Characteristics of Lubricating Oils

ASTM D6082 - IP 453



 	High temperature stability
$\Theta \Phi \Phi \Phi \Phi$	Up to four positions per bath
Φ	Clamps and rack to hold cylinders
Φ	Bath Drain
Φ	Robust

Item	Unit	Foaming Bath		
P/N 230V/50-60Hz		00T0340		
P/N 115V/60Hz		00T0341		
Power 230V	[kW]	2		
Power 115V	[kW]	1.2		
Range	°C	Ambient 160		
Outer bath material		Stainless steel cover, zincor powder coated case and borosilicate glass windows		
Inner bath material		Borosilicate glass jar		
Cylinders		1000 mL, borosilicate glass		
Positions		4 openings per bath		
L x W x H Bath	[mm]	380 x 430 x 710		
L x W x H Rack	[mm]	300 x 430 x 520		
Weight	[kg]	32		
Bath volume	[L]	Up to 31		
CE		Conforms to CE regulation		
Heating	[kW]	2.8 (230V) 2.1 (115V)		

General

ASTM D6082 covers the determination of the foaming characteristics of lubricating oils at 150°C. The tendency of oils to foam can be a serious problem in systems such as high-speed gearing, high-volume pumping, and splash lubrication. Inadequate lubrication, cavitation, and overflow loss of lubricant can lead to mechanical failure. This test method is used in the evaluation of oils for such operating conditions.

Construction

The Tamson D6082 apparatus consists of a visibility bath and a rack. The bath is used as a high temperature bath. The bath is constructed with a glass jar with a diameter of 300 mm and a height of 450 mm. Around the jar is a zincor powder coated case equipped with two glass windows and a stainless steel cover. The bath has two cooling coils and has the capacity to hold up to four 1000 ml graduated glass foam cylinders. The bath is equipped with RS232 communication port. Next to the bath, the apparatus is supplied with a rack to hold up to four foam cylinders. On this rack two flow meters are mounted and there is space for an optional dryer tower to be mounted on the same rack.

The rack also comes with a spill tray which can be removed for cleaning purposes. The Tamson high temperature foaming apparatus is standard supplied as shown in table 1 on the next page, suitable for two test positions in the bath. Two flow meters are included. Custom-made configurations are available on request.

Primary benefits of Tamson D6082 apparatus

- Up to four positions per bath
- Rack with clamps to overcome the buoyancy of the foam cylinders
- Stirrer with long shaft for optimal temperature uniformity
- Delrin stoppers instead of rubber stoppers, as rubber stoppers can crack over time
- Levelling feet to ensure the bath spirit is level
- Separate opening in cover to add bath medium to make sure the foaming cylinder is immersed to the 900 mL mark
- Robust zincor powder coated case around glass jar
- Removable outside window panels for cleaning purposes
- Bath is equipped with two cooling coils and can be used for ASTM D892 if needed
- Thermometer openings in cover
- Stainless steel cover



High Temperature Foaming Characteristics of Lubricating Oils

ASTM D6082 - IP 453

Accuracy

The Tamson foaming bath has a very high temperature stability, because it has a stirrer with a long shaft, resulting in better temperature uniformity inside the bath. The set point can be set in steps of 0.01°C (two decimals) in the range of 0°C up to 160°C (32..320°F). The readout is displayed in two decimals.

Temperature readout

Standard available in °C, on request in °F.

Safety

The bath conforms to CE regulation. It is further equipped with a mechanical resettable safety thermostat. A float is included and will indicate when the bath fluid is too low. The fumes from the test oil and the bath shall be vented in a manner compatible with local government regulations.

ASTM D892

Tamson also supplies an apparatus conform ASTM D892 (foaming characteristics at 24°C and 93.5°C). For an apparatus suitable for ASTM D892 and ASTM D6082, please see the ASTM D892 specification sheet.

Table	1: Apparatus ASTM D6082 P	/N 00T0340	or P/N 00T0341 consists of the following parts:
P/N	Picture	Quantity	Description
00T0325		1	Tamson foaming bath, 230V/50-60Hz. Thermostatic bath with temperature range from ambient till 160°C. Equipped with float. Cover has four openings with clamps to insert four foam cylinders. Bath is equipped with a rack to hold the foam cylinders. Two additional openings are available for thermometers. Another opening can be used to add bath fluid. Bath is equipped with two cooling coils
00Т0326			Tamson foaming bath, 115V/60Hz. Thermostatic bath with temperature range from ambient till 160°C. Equipped with float. Cover has four openings with clamps to insert four foam cylinders. Bath is equipped with a rack to hold the foam cylinders. Two additional openings are available for thermometers. Another opening can be used to add bath fluid. Bath is equipped with two cooling coils
31T0096		1	Stainless steel bracket to hold four foaming cylinders and four stoppers. The rack is delivered with two calibrated flowmeters and connectors, which can be mounted on the rack. Each flowmeter is delivered with a works certificate. Rack is including leakage tray. Also, the optional dryer tower can be mounted on the rack
09T0223		2	Foaming cylinder with NS45/50 joint, 1000 ml, borosilicate glass, graduated
31T0160		2	Delrin stopper with O-rings for foam cylinder with opening for air inlet tube and a second opening for air outlet tubing. Stopper is including quick connectors and inlet tube
34T0000		1	Blue PU tubing 6 mm, 50 meter. Setup delivered with tube cutter (P/N 34T0005)

Tamson Instruments Specification sheet

High Temperature Foaming Characteristics of Lubricating Oils

ASTM D6082 - IP 453

Table 2: Required Accessories for ASTM D6082			
Item	Picture	Suggested quantity	Description
11T0036		1	Pressure pump with valve 230V/50-60Hz
11T0037			Pressure pump with valve 115V/60Hz
31T0066W		2	Mott cylindered metal diffuser, made of sintered five micron porous stainless steel, with work certificate for permeability and porosity

	Table 3: Optional Accessories for ASTM D6082				
ŀ	tem	Picture	Suggested quantity	Description	
31	T0067	River	1	Wet test meter (volume measuring device), for accurate measuring of the gas volumes required by the test method	
31	T2044		1	Gas drying tower, 75 mm x 289 mm, with 1/8" stainless steel NPT fittings and connectors to mount on D892/D6082 rack (P/N 31T0096)	
31	T0028	Anderson	1	Digital stopwatch 1/100 second	
25T0	0934BW		1	ASTM similar to 41C thermometer, range from +98 to +152°C with non-hazardous blue filling and works certificate	
31	T0423		1	Cork for bath thermometer, pack of ten pieces	

High Temperature Foaming Characteristics of Lubricating Oils

ASTM D6082 - IP 453

Continued table 3: Optional Accessories for ASTM D6082			
Item	Picture	Suggested quantity	Description
00Т0223	UP?	2	Bath fluid synthetic base stock (polyalphaolefin), 20 litres transparent, 80200°C
00Т0911		1	Illuminator "Z41" backpanel (85 ~ 230V/50-60Hz)
31T0066		2	Mott cylindered metal diffuser, made of sintered five micron porous stainless steel. This gas diffuser is supplied without certificate. For a certificate please use P/N 31T0066W
31T2076		1	Airflow meters suitable for a flow rate of 300 ml/m. Supplied with works calibration certificate and one-on- one hose connection, when not using the rack (P/N 31T0096)





Tamson Instruments Specification sheet

High Temperature Foaming Characteristics of Lubricating Oils

ASTM D6082 - IP 453

Table 4: Consumables for five years of operation:			
Item	Picture	Quantity	Description
09Т0223	(I) The second of the second	2	Foaming cylinder with NS45/50 joint, 1000 ml, borosilicate glass, graduated.
24T0400	0	5	Upper O-ring 38 mm I.D. for stopper (P/N 31T0160)
24T0401	0	5	Lower O-ring 36 mm I.D for stopper (P/N 31T0160)
28T4163		2	Push-in fitting short, L-shaped, 6 mm O.D. for stopper (P/N 31T0160)
28T4507		2	Messing connector 6mm hose 1/8" for stopper (P/N 31T0160)
34T0048		3	Hose adapter 6mm O.D. to G1/4" quick fit
34T0061		2	Hose adapter T-shaped 6mm O.D. to G1/4" quick fit
31T2041		1	Refilling for dryer (P/N 31T2042), 5 lbs, 8 mesh

